

---

# Cloud Management for the EN-2000

You can register your EN-2000 for cloud management. This document provides information for connecting your EN-2000 to enCloud™, Encore Networks' cloud management system.


Cloud connection provides management of your connected Encore devices via a web portal to enCloud. The enCloud management system supports Encore Networks' EN-1000™, EN-2000™, and EN-4000™ routers.

## B.1 Setting Up the EN-2000 to Send Data to enCloud

The enCloud system can manage Encore Networks' EN-1000s, EN-2000s, and EN-4000s. This section presents a quick overview of the process for a device to send its information to enCloud. (The EN-1000 and the EN-2000 are configured in the same way. The example uses an EN-2000.)


- 1 In the EN-2000's management system, select the **Network** tab; then select the **Interfaces** tab.
  - ❖ The EN-2000 Interface Overview Screen is displayed ([Figure B-1](#)).

Figure B-1. EN-2000 Interface Overview Screen



- 2 On the EN-2000 Interface Overview Screen, select the **Network** tab; then select the **enCloud** tab.
  - ❖ The EN-2000 enCloud Configuration Menu is displayed (Figure B-2).

Figure B-2. EN-2000 enCloud Configuration Menu



- 3 This menu specifies the connection to enCloud. Make sure the field **enCloud Enabled** has the value **Yes**. Get other settings from your network administrator.
- 4 Select the **Save & Apply** button.
  - ❖ The EN-2000 will send information to enCloud.
- 5 Log into enCloud to monitor and interpret information about this EN-2000.