



---

# Module for the enCloud™ Management System

**T**You can manage your EN-1000™, EN-2000™, or EN-4000™ via a direct connection to your computer, or over a LAN, or in several other ways, including through Encore Network's enCloud™ management system. The enCloud™ system lets you manage your network from anywhere with a connection to the internet. You can use a computer, a tablet, or a smartphone to manage your devices. Development and use of enCloud™ is discussed in the documents listed below.

## List of Documents

The *Module for the enCloud™ Management System* contains the following documents:

- Set-Up Documents
  - › [QuickStart Guide for the enCloud™ Management System](#)
  - › [Account Registration and Log-In for the enCloud™ Management System](#)
- Core Documents
  - › [Developing Accounts in the enCloud™ Management System](#)
  - › [Use Cases and Groups in the enCloud™ Management System](#)
  - › [Devices and Hardware Profiles in the enCloud™ Management System](#)
  - › [Establishing Users and Contacts for the enCloud™ Management System](#)
  - › [Developing Rules for the enCloud™ Management System](#)
- For the EN-1000™, EN-2000™, and EN-4000™:
  - › [Setting Up a Device to Send Data to enCloud™](#)
- Additional Documents for Operation
  - › [Using the enCloud™ Management System to Update Firmware](#)
  - › [Sensors for enCloud™ Management System Rules](#)
  - › [Settings for the enCloud™ Management System](#)
- Catalog Documents
  - › [Table of Contents](#)

You may download documentation for enCloud at  
[http://www.encorenetworks.com/document\\_catalog.htm](http://www.encorenetworks.com/document_catalog.htm).

